


User manual

ALFA 52 VS 0-20°C

Differential Thermostat.



VDH doc. 080331

Versie: v1.2

Datum: 22-04-2010

Software;	File: Do080331.wpd	Static range (see sticker);
992903 ALFA 52/72 VS 20 -50..+50	Typenr.: 904.000806	-50/+50,0°C
100320 ALFA 52/72 VS 20 -20..+80	Typenr.: 904.000929	-20/+80,0°C
992901 ALFA 52/72 VS 20 0..+100	Typenr.: 904.000916	0/+100,0°C

* **Installation.**

On the connection diagram of the **ALFA 52-VS** is shown how the sensors, power supply and relays has to be connected. After connecting the **ALFA 52-VS** to the power supply, a self test function is started. As this test is finished, the measured differential temperature of sensor-1 minus sensor-2 appears in the display.

* **Control.**

The **ALFA 52-VS** thermostat can be controlled by four pushbuttons on the front These keys are:

- SET** - view / change set point and reset the alarm
- ▲ (UP)** - increase the set point.
- ▼ (DOWN)** - decrease the set point.
- MODE** - relays status key.

* **Viewing the temperature from sensor-1 and sensor-2.**

By pressing the **UP** and **DOWN** keys simultaneously and after that the **UP** key, the measured value from sensor-1 can be read-out. If the down key is pressed, the measured value from sensor-2 is shown. If no key is pressed for a few seconds, the differential temperature is shown again.

* **Viewing the delta-setpoint.**

By pushing the **SET** key, the set point of delta thermostat appears in the display.

A few seconds after releasing the keys the setpoint disappears and the differential temperature is shown again in the display.

* **Changing the delta-setpoint.**

Push the **SET** key. The delta-setpoint appears in the display. Release the **SET** key. Now push the **SET** key again together with the **UP** or **DOWN** keys to change the set point. A few seconds after releasing the keys, the measured differential temperature is shown again in the display.

* **Status of the Relays.**

By pushing the **MODE** key the display shows the status of the relays.

Each digit shows the status of one relay output, showing 0 = off and 1 = on.

The code 110 means relay 1 and 2 are on and relay 3 is off.

Relays 1 and 2 are used for the differential thermostat (see function diagram).

Relay 3 is used as an alarm relay.



* **Adjustment sensors.**

Sensor-1 can be adjusted by using the Sensor Offset parameter 05 and Sensor-2 can be adjusted by using the Sensor Offset parameter 06. Indicates a Sensor e.g. 2°C too much, the according Sensor Offset has to be decreased with 2°C.

* **Error messages.**

On the display of the **ALFA 52-VS** the following error messages can appear:

E1	- Sensor-1 failure.	Solution E1, E2:
E2	- Sensor-2 failure.	- Check if sensor is connected correctly.
		- Check sensor (1000Ω at 25°C)
		- Replace sensor
EEE	- Settings are lost.	Solution EEE:
		- Reprogram the settings.

Reset Alarm. When an error-messages appears it can be reset by pushing the **SET** key. The function of this key depends on parameter P42.

After reset alarm the differential temperature appears again in the display or the error-code **E..** alternates with extra indications as the temperature is out of measure range. These indications are:

'L' indicates a short-circuit sensor.

'H' indicates a open-circuit sensor.

Whereby the first segment is used to indicate these codes for Sensor-1 the second segment shows 'L' and the last segment indicates the codes for Sensor-2.

F.i.;	L - -	Indicates a short circuit of Sensor-1 and Sensor-2 okay
	- - H	Indicates a open-circuit of Sensor-2 and Sensor-1 okay
	H - L	Indicates Sensor-1 with a open-circuit and Sensor-2 with a short-circuit

* **Technical data ALFA 52-VS.**

Type	: ALFA 52-VS Differential thermostat (Rail)	
Range	: Differential temperature in display 0/+20°C (0,1)	
Static range sens.	: -50/+50,0°C, above -10°C read-out in 0,1°C or -20/+80,0°C, above -10°C read-out in 0,1°C or 0/+100,0°C, read-out in 0,1°C	
Supply	: 230Vac 50/60Hz (-5/+10%) or else see product sticker	
Read-out	: 3-digit 7-segments display	
Relays	Ry1= SPST(NO)	250V/8A (cos φ=1) or 250V/5A (cos φ=0.4)
	Ry2= SPST(NO)	250V/8A (cos φ=1) or 250V/5A (cos φ=0.4)
	Ry3= SPDT(NO/NC)	250V/8A (cos φ=1) or 250V/5A (cos φ=0.4)
	Relays have one common (C).	
Control	: by push buttons on the front.	
Front	: Polycarbonate	
Sensor	: 2x SM 811/2m (PTC 1000Ω/25°C).	
Dimensions	: 90 x 71 x 58mm (hwd)	
Panel cut out	: 46 x 71mm (HW) at panel mount	
Accuracy	: ± 0,5% of the range.	

- Provided with memory protection during power failure.
- Connections with screw terminals on the back side.
- Equipped with sensor failure detection.
- Special versions on request available.



* **Setting internal parameters.**

Next to the adjustment of the set point, internal settings can be made like differential, sensor offset, set point range and the functions of the thermostat.

Push the **DOWN** key for more than 10 seconds, to enter the 'Internal Programming Menu'. In the left display the upper and lower segment are blinking. Over the **UP** and **DOWN** keys the required parameter can be selected (see table for the parameters).

If the required parameter is selected, the value can be read-out by pushing the **SET** key. Pushing the **UP** or **DOWN** key to change the value of this parameter.


If 20 seconds no key is pushed, the **ALFA 52-VS** changes to the normal operation mode.

* **Parameters ALFA 52-VS**


Para-Meter	Description Parameter	Range	Default value
05	Offset temperature sensor 1	-15.0..+15.0°C	0.0
06	Offset temperature sensor 2	-15.0..+15.0°C	0.0
10	Switching differential	0.1..20.0	0.5
11	Switch on delay	0..99	0
12	Switch off delay	0..99	0
13	Parameter 11/12 in seconds or minutes	0 = seconds 1 = minutes	0
20	Minimum adjustable delta-setpoint	0.0..+20.0°C	0.0
21	Maximum adjustable delta-setpoint	0.0..+20.0°C	20.0
22	Read-out above -10°C on whole degrees	0= No 1= Yes	0
40	Relay function alarm relay	0= fail safe alarm 1= control alarm	0
41	Reset alarm relay after recovered alarm	0= No 1= Yes	0
42	Reset alarm relay after manual reset	0= No 1= Yes	0
45	Control delay after power failure	0..99 min.	0
46	Relay active at error control sensor	0= Non 1= Relay 1 2= Relay 2	0
95	Software version	0..255	0
96	Production year	00..99	0
97	Production week	1..52	1
98	Serial number (x1000)	0..255	0
99	Serial number (units)	0..999	0

* **Function diagram.**


FUNCTION DIAGRAM ALFA 52/62/72-VS



* **Dimensions.**



* **Connections.**



* **Address.**

VDH Products BV
 Produktieweg 1
 9301 ZS Roden
 Nederland

Tel: +31 (0)50 - 30 28 900
 Fax: +31 (0)50 - 30 28 980
 Email: info@vdhproducts.nl
 Internet: www.vdhproducts.nl

